



1. Start with the cooler upside down.



3. Loop the long strap thru the slots in the wheel brackets and thru the cam buckle avoiding twists.



All Detrain Wheel System
Works with YETI Tundra
Goolers 50 thru 160

2. Set the wheel brackets in place so that they nest inside the recesses on each end of the cooler.



4. Pull it tight, not letting it slip, keeping the cambuckle close to the wheel bracket.



5. Tuck the end of the strap back thru the slot in the wheel bracket and then under itself.





****Note** **

Now you can cut the excess strap and melt the end to prevent fraying. We recommend 10 to 15 inches of extra strap for tightening.



6. Flip the cooler over onto the wheels and secure one short strap from the wheel bracket to the integrated tie-down slot.



7. On the other side, pull down the knots of the rope handle.



8. Push the handle bracket up into the molded in handle of the cooler.



9. Drop the strap thru the integrated tie-down slot.



10. Pull down the rope handle.



11. Secure the final short strap, and you are ready to roll.