

All Terrain Wheel System

Rambler X2

Works with YETI Tundra Coolers 50 thru 110.



Telescoping
Switch-Grip
Handle

TWO AXLE
POSITIONS

COOLER CUSHION
RUBBER BUMPERS

SHORT & LONG
SS Cam Buckle
STRAPS

NEVER FLAT
All-Terrain
WHEELS



1. Weave the long strap through the holes in the wheel bracket in this pattern, avoiding twists, with the cam buckle facing down. Do not thread the cam buckle yet.



2. Drop the cooler down onto the wheel bracket (drain plug side) with the long strap stretched out under the cooler in the pattern from step 1. Keeping the strap free of slack, make sure the cam buckle is positioned no more than 2 inches from the cooler.



3. Now, moving to the other side of the cooler, thread the short strap down thru the integrated tie down slot of the cooler to the wheel bracket and back up thru the cam buckle, but do not tighten.



4. Back to the other side of the cooler, pull down the knots of the rope handle.



Check out our videos on YouTube for more information and instruction on installing and using your Rambler.

Made in the USA



5. Push the handle bracket up into the molded in handle of the cooler.



6. Drop the strap thru the integrated tie-down slot.



7. Pull down the rope handle.



8. Thread the long strap thru the dangling ring.



9. Wrapping the strap around one hand and placing the other on the top of the closed cooler, pull the strap tight with an upward motion.

This may take a couple of tugs to accomplish a tight fit. The wheel bracket should pull snug to the other side of the cooler.

Now you can cut the excess strap and melt the end to prevent fraying. We recommend 10 to 15 inches of extra strap for tightening.



10. On the other side of the cooler, tighten the short strap. If you have the buckle positioned like in the picture, this should be a downward tug.

If done properly, the Rambler should now be tight to the cooler. The wheel bracket should be centered and snug.

Again, now you can cut the excess strap and melt the end to prevent fraying. We recommend 10 to 15 inches of extra strap for tightening.

****Here's a tip, tuck the 10 to 15 inches of slack back thru the ring to keep it out of the way.**

*****The Rambler ships with the axle in the higher position (level cooler position). If more clearance is desired, pull the pin clip out of the axle, remove the wheel assembly, and re-assemble on the lower axle position (all terrain position).**

Questions? Contact us at ramblerwheels@gmail.com



Cooler not included.